



**Quantum
Analytics**

FOR USE WITH AGILENT TECHNOLOGIES LABORATORY SYSTEMS

> INTEGRITY MAX SERIES UPS LINE

Our NXT Power Integrity Max is a true online double conversion UPS. Its sleek, forward-thinking, and eco-friendly design provides stable and uninterrupted power for your mission-critical application with industry-leading efficiency, durability, and performance.

POWER QUALITY YOU CAN RELY ON

The industry-leading UPS Line is built to power sophisticated computer loads—systems with high inrush current and high crest factors—which eliminates oversizing and reduces operating costs. You can custom design the output receptacle panel and input line cord for faster and simpler onsite set up.



SUITABLE FOR USE WITH:

- > Clinical Diagnostics Application
- > Analytical Laboratory Systems
- > Sophisticated computer loads
- > Industrial Microprocessor Equipment

SUPERIOR POWER PROTECTION BENEFITS & FEATURES

- Help your customers protect their electronic systems and ensure uninterrupted uptime all day, every day
- Enjoy peace of mind knowing equipment is protected from problems due to common-mode voltage, power outages, spikes and transients, and more
- UL Listed and CE marked
- Worldwide voltage and frequency options provided by online inverter
- Unity output power factor for most units
- Stable output over a wide range of input voltage and frequencies
- Online double conversion topology. Product line options range from 2 kVA to 10 kVA
- All models include NXT Power three-year warranty on batteries, parts, labor and on-site service.

NXT POWER

DELIVERING ULTIMATE POWER PROTECTION



PURCHASE OR INQUIRE THROUGH
QUANTUM ANALYTICS

800-992-4199 INFO@LQA.COM
WWW.LQA.COM

MODEL #	INPUT VOLTAGE AC [~]	NXT POWER PART #	INPUT PLUG	WALL VOLTAGE & RECEPTACLES	VA/W
6400/6500 Series MS + 1200 Series HPLC stack & PC/monitor	208	32-00520-52	L6-30P	208, 30A L6-30R	5.2k/5.2k
7800/7850/7900 ICP-MS + SPS4 AS or I-AS & PC Monitor	208	32-00520-60	L6-30P	208, 30A L6-30R	5.2k/5.2k
7800/7850/7900 ICP-MS + SPS4 AS or I-AS, Chiller (G3292A) & PC Monitor	208	32-00820-55	6-50P	208, 50A 6-50R	8.2k/8.2k
6890/7890/8890 GC w Fast Oven 5900 Series MSD & PC Monitor	208	32-00420-54	L6-30P	208, 30A L6-30R	4.2k/4.2k
6890/7890/8890 GC w Fast Oven + PC/monitor	208	32-00320-75	6-20P	208, 20A 6-20R	3.2k/3.2k

ADDITIONAL PRODUCT INFORMATION

- Enclosure: 28.4 in x 11.75 in x 33.0 in
- Unit weight for model NPTU2200-0 to NPTU60000-0 is 266 LBS/121 KGS
- Unit weight for model NPTU8200-0 to NPTU10.0-0 is 317 LBS/144 KGS

ADD-ONS

- We offer additional battery cabinets and seismic brackets for all UPS models.
- Custom PDU (rear panels)

Contact your sales representative for more information.

**WE ARE DEDICATED TO PRODUCING THE
BEST POWER QUALITY SOLUTIONS AND
PRODUCTS FOR YOUR BUSINESS.**

We manufacture power quality solutions using proven technology and the latest industry knowledge to deliver the cleanest, most reliable power available to businesses in a diverse range of markets and industries.

NXTPOWER

DELIVERING ULTIMATE POWER PROTECTION



PURCHASE OR INQUIRE THROUGH
QUANTUM ANALYTICS
800-992-4199 INFO@LQA.COM
WWW.LQA.COM